

INSTRUCTION

STEP 1 - Set up your working space

Candle making can be messy, so prepare your work area! Make sure to work on a heat resistant surface or cover the area with heat resistant material. You can use aluminum foil or butcher block paper. Do not use newspaper or wax paper, as heat will transfer ink and wax to the surface.

STEP 2 - Place a glue dot on the metal base of a wick and press it firmly in the middle of the candle tin

Place the craft sticks on top of the container. The sticks have a small hole in the center for the wick to go into. This stick is to make sure the wick is staying centered when the melted wax is poured into the tin.

STEP 3 - Melt the wax

IMPORTANT! Do not use direct heat when melting the wax! Also - do NOT use microwave!

Fill a medium saucepan $\frac{1}{2}$ full of water and place it on the burner or hot stove. Empty 1 bag of soya wax into the pouring pot. Place the pouring pot into the water filled pot and heat over medium-low heat. Be sure to monitor the water level and fill more water if needed.

Melt the wax until completely smooth. Stir the wax occasionally by using a wooden spoon. Use the thermometer to make sure the temperature does not exceed 185 degrees Fahrenheit. Lower or higher the temperature as needed.

STEP 4 - Add the color

Once the wax is fully melted add a color of your choosing and stir until fully incorporated.

STEP 5 - Add the scent

Pour 1 bottle of your choosing into the melted wax and stir while keeping the heat on low-medium heat. Mix vigorously for a full 2 minutes to achieve the best scent throw from your candle.

Note: After 2 minutes, once the scent are completely blended with the wax, turn off the heat and remove the pouring pot from the heat source.

STEP 6 - Pour the wax into the candle container

Carefully pour the wax leaving $\frac{1}{4}$ inch to the top in order to make room for the wick to stick out as well as enable to close the lid completely. Do not pour directly on the candle wicks! Make sure the candle wicks remain centered after pouring.

CAUTION! Keep children away when pouring the melted wax!

WELL DONE! What's next?

Let your candle cool down. Leave the lid open and let your candles cool for at least 2 days before lighting them for the first time. The 2-days waiting period is extremely important in order to achieve the best scent throw out of your candles. Trim the wicks to $\frac{1}{4}$ above the candle.

The logo for Artzeke Art & Craft features the brand name 'Artzeke' in a large, elegant, cursive script. Below it, the words 'Art & Craft' are written in a smaller, clean, sans-serif font.